

HP Consumer Systems

- [BIOS](#)
 - [CMOS Reset - HP Elitebook 800 Series](#)

BIOS

CMOS Reset - HP Elitebook 800 Series

To reset the CMOS:

- Hold POWER for 45 seconds.
- When released, the CAPS LOCK indicator light will become lit for 5-7 Seconds.
- Wait 10 Seconds before pressing POWER.