

CMOS Reset - HP Elitebook 800 Series

To reset the CMOS:

- Hold POWER for 45 seconds.
 - When released, the CAPS LOCK indicator light will become lit for 5-7 Seconds.
 - Wait 10 Seconds before pressing POWER.
-

Revision #3

Created 2024-03-26 14:10:46 UTC by TwiStar Legend

Updated 2024-03-26 15:00:39 UTC by TwiStar Legend